



UNISONICS

AUSTRALIA

ULTRASONIC CLEANING

WELCOME

Welcome to issue two of the Unisonics newsletter. This issue covers the release of the gun cleaning package as well as handy tips on the performance test needed to be carried out on the ultrasonic cleaning system.

New Products

Gun cleaning will quickly and effortlessly remove the carbon residue, grease and dirt in and around all the sections of the gun.

This is a time saver, money saver and provides the best quality in your gun.

A package deal has been put together for easy cleaning.

Efficiency Test

It is better to discover the inefficiency of a ultrasonic cleaner, sooner rather than later and to minimise further losses through poor ultrasonic cleaning.

- Cut a section of Aluminium Foil the length and depth of the Ultrasonic Tank
- Immerse section of aluminium foil into the liquid in a vertical hold
- The foil must not make contact with tank bottom and be left for a duration of 30 seconds
- A consistent pattern of perforation should result with hole sizes varying from one to four mm in diameter
-

Results: If you have blank areas of foil in the test area that have no holes this would indicate that the ultrasonic cleaner is not working properly in that part of the tank.

The ultrasonic cleaner should be serviced if performance test fails.

Unisonics advises to submit equipment earlier rather than later to avoid further operating problems.

Coming Attractions

- Golf Club Pro Clean

April Specials

PS-30GUN PACKAGE



Unisonics is offering a package deal for the month of **APRIL ONLY.**

PACKAGE INCLUDES

- Ultrasonic Cleaner Model PS-30
- Lid
- Basket
- Protective Platform
- 3.8L Cleaning Solution
- Lubricant

The PS-30 Ultrasonic Cleaner Package is designed to remove carbon and grease from your handgun using the most advanced technology available.

(See website for more details)

**ONLINE SHOPPING
AVAILABLE**